

Step 1

Select the right spot



Use the pictorial guide and find the most suitable spot for the small tab

Clean the selected spot with a bit of water and a paper towel to ensure there is no debris or dust on the shoe sole.

Once clean, open the white sachet provided in the pack.

Step 2

Prime the area.



Use the towelette from the sachet to prepare the surface on the sole where you have chosen to stick the strap. Ensuring to get right into the grooves of the sole.

Step 3

Position small
tab.



Without using any pressure, lightly stick the small tab of the strap on the sole. Ensure that almost none of the stem section is fitted under the shoe sole as shown.

Step 4

Work the grooves.



Make sure to work the tab right into the grooves of the sole. If needed, you may use a flat tool to get good pressure as pictured.

Start at the grooves closest to the stem of the strap and work out towards the end of the tab.

Apply good pressure to get right into corners

Step 5

Finish the job.



Once the strap is fitted securely to the sole, you can stick the stem firmly to the sidewall of the shoe and the larger tab inside the shoe.

For best results, let the adhesive cure overnight before use.